

7. Fix the elastic loop to the harness-line tie down or around the mast, to keep the webbing loop and buckle at your fingertips and not swinging around.



8. For extra-easy trimming on-the-fly, use the "Unifiber Sail Outhaul Double Pulley" (not included).



9. Pull the webbing loop to increase outhaul tension.



10. Pull the buckle away from the boom to release outhaul tension.



ADJUSTABLE OUTHAUL SET EASY

Instruction manual



ADJUSTABLE OUTHAUL SET EASY

1. Lay out your outhaul set alongside the boom arm with the elastic towards the boom head.



2. Wrap the outhaul set around the boom and pass it through the grey rope loop.



3. Once wrapped around the boom it should look like this.



4. Check if the elastic is facing the boom head, and the buckle to the boom tail.



5. Feed your outhaul rope through the webbing loop behind the buckle.



6. Tie off with a solid knot. Then repeat the same sequence on the other side of the boom.

