

OPERATING INSTRUCTIONS

A. Reset combination lock

1. Read ALL the instructions before starting the resetting procedure.
2. Open the safe with the default combination: 0-0-0-0
3. Slide the reset pin to the right and upward.
4. Select your desired combination on the dials. Ensure that the numbers are positioned centrally and have clicked into position.
5. Don't forget your combination! Or you will lose valuable surfing time!
6. Slide the reset pin back into its original position.

B. Release shackle`

Slide the release button inside the safe to the right and pull the shackle upward.

A. Reset combination lock



B. Release shackle

